



1. Connect two bottom AL cable together with screws and add about 2 slip slots on it.



3. Add the oriented slots for Rafter to form the roof

4. Connect the upper AL cable together with screws

2. Put the each bamboo lattice wall into the slots



5. After assembled the wall frames, it need one man hold the Center ring sitting in a lift in the center of the frame, after that the other man need to Put the bamboo rafters into Center ring from the oriented slots and form the roof .



6. Add the decorated cloth as the first inner cover



7. Add the several cotton felts as the second inner cover, and use velcro connect with each other. It can keep heat preservation function.



8. Add the cloth plated with silver as the third cover, and it can prevent ultraviolet radiation.



9. Add the embroidery cloth as the outside cover and it looks beautiful.



10. Put the skylight on the top of the roof.



11. Screw the skylight into the hole of the center ring and make them together and strong, you can also leave a little space between each other to keep ventilated.



12. See the door and inside of the yurt, the lattice wall made from so many strong bamboo and the rafters is made from 3cm diameter bamboo.



13. See the outlook of Yurt, It's ecotype tent and easy for assembly.



Note: All above just our simple instruction for assembly